

Apply Instruction



How to Use the Spin Doctor Leveling System

- 1, Place your tile in the desired position
- 2, Position the threaded spacer posts under the exposed edges of the tile to best suit the tile size and layout. Posts can be used in multiple configurations, such as a linear spacer, a "T" spacer, or a four-corner spacer
- 3, Make sure there is direct contact between the spacer and the tile without mortar in between
- 4, Place the rotating cap on the top of the threaded spacer post and spin the cap down to the tile surface
- 5, Turn cap as needed until all adjacent surfaces are flush
- 6, Remove spacer posts and caps with a rubber mallet once tile adhesive has cured
- 7, Caps are easy to clean and re-use!